

## WR TACTICAL AD-ONS

- **FLOORPLATE PIC RAIL**
- **BARRICADE STOP**
- **DOPE CARD HOLDER**

DESCRIPTION: Ad on items for tactical precision shooting, sturdy hold, quick dope referencing, etc. All bolt on.

OPTIONS AND PARTS:

**WR Floorplate Pic Rail:** attaches to the WR T3 floorplate to allow under-gun accessories.



**WR Barricade stop and handle support:** Attaches to any pic rail mount.



**WR Dope Card Holder (Rigid):** To hold sight setting cards, messages, reminders, etc. Connects to your

**WR Dope Card Holder (Flexi):** The same as the rigid unit, but is on a flexible wire and Velcro attaches to an opposite Velcro patch secured to the firearm.



SPECIAL FEATURES: Each part can be used independently or in combination. All items are sturdy and are used in a variety of applications. Simple attach and detach mechanisms. Simple to use.

EQUIPMENT NEEDED:

- Barricade Stop and Rigid Dope Card Holder requires a 4mm hex key for the cross bolts.
- The Floorplate pic rail only attaches to the WR T3 Floorplate requires a 4.5mm hex key.

KNOW THE ITEM: There is no one way for each shooter to use these items. The basics of their purpose are pretty obvious, but really getting the most out of the items will be by developing ones own techniques.

#### FITTING:

- **T3 Floorplate Pic Rail** only fits to the WR T3 Floorplate. It slots into the WR floorplate front takedown screw recess and uses its own longer takedown screw. Simply remove the current front takedown screw, place the pic rail into the front floorplate recess then insert the new pic rail screw and tighten to normal tension (5Nm or 50 in-lbs).
- **Barricade Stop** connects to a pic rail by way of a base that clips over the pic rail and screws tight. The screw should be done up reasonably tight, but do not over-tighten...there is no need to. Due to the nature of the barricade stop, the female pic rail boss should usually face to the rear, however there is no real right or wrong depending on how the shooter will use it. Location/position on the firearm is also totally open to user preference. Tighten screws only to moderate tightness...do not over-tighten.
- **Dope Card Holders** should be positioned such they minimise obstruction to your down-range view, but are not difficult to see the information. Attach to the top, bottom, side, or wherever you feel is necessary to be useful but not a hindrance. Note, the rigid holder is subject to breakage if hit, so should not be leveraged off. Tighten the screws to moderate tightness. Do not over-tighten.
- **Flexible Dope Card Holder** simply connects to the hook piece of Velcro. Simply anywhere on a rifle where the dope card holder is best to be connected (and it can be multiple places) simply stick a piece of hook Velcro on that spot of the rifle. Then the loop side of the Velcro will connect to it.

#### ADJUSTMENTS:

- **T3 Floorplate Pic Rail** is not itself adjustable, but with multiple pic rail slots, items attaching to it can be in multiple points along its length.
- **Barricade Stop** connects along any length of a pic rail.
- **Dope Card Holders** are made to be adjustable, to maximise the shooter ability to have contained information readable while in a shooting position, preferably without the forward firing and target view not be obscured.

**SERVICING & MAINTENANCE:** Like all things shooting, keep clean. Ensure surfaces that are tightened are clean before tightening up the clamping parts.

**SPARE PARTS:** Email via the website for any spare parts. [www.watersrifleman.com](http://www.watersrifleman.com) with any enquiries.

\* \* \* End \* \* \*